

## How to identify your PDI handheld model

On the back of every handheld is a sticker with the model number.



### Model X3/X3+/X4

**Warm Boot** - To perform a warm boot, press and hold the following keys simultaneously:



(yellow) + (blue) + Esc

**Cold Boot** - To perform a cold boot, do the following steps:

1. Remove the battery pack
2. Press and hold the **SCAN** button and the black **Reset** button in the handheld's battery compartment.



3. Insert the battery pack. The handheld displays the DATALOGIC screen and then reboots.
4. Use the stylus to recalibrate the handheld.